# SRL-443 MAGIC FINGER USER MANUAL

SRL-443 MAGIC FANCER is a kind of disco light by using light beams to produce beautiful designs, which is suitable for small and middle sized entertain occasion.

I. **Technical Date:**

| | |
|---|---|
| Name: | MAGIC FANCER |
| Type: | SRL-443 |
| Lamp: | J TYPE 230V/300W |
| Voltage: | AC 220V~240V 50Hz |
| Color: | 6 dichroic colors |
| FUSE: | 3.15A/250V |
| Weight: | 4KG |
| Measurement: | L360XW350XH200 mm |

## II. Operational Instructions:

1. Unpack the carton to check if there is any damaged or missing parts when you receive the unit, call the local dealer if anything is found not in a normal condition.
2. Open the lid to install lamp. Keep the lamp untouched by hand and disconnect the unit from power while Re-lamping.
3. Use a clamp to hang the unit onto the truss fasten tight. Tie the steadily onto the truss by winding a chain through the bracket of the unit.
4. Place the unit where there is efficient ventilation, away from any flammable and explosive objects.
5. Check that the rated power corresponds to the main supply.

**III. Bulb installation / Replacement**

1. Before opening unit, make sure that the unit is cool and is not connected to any power source.
2. Remove the screw on the access door on the top of the unit . lift access door open.
3. Install/replace halogen bulb. Make sure the bulb is in securely; do not touch the glass on the bulb with your bare hands, if you touch the glass, clean it with alcohol using a cotton ball or soft cloth.
4. Close the access doors and tighten the screws.

**IV. Caution:**

**Never** open this unit when it is hot and / or is connected to a power source.

**We** recommend extending the life of the unit that you use a chaser with this unit, or cycle the use of the unit by giving the unit a break after 30 minutes of continuous use.

**Never** use this unit in a wet and/ or dusty room.

**Replace** bulbs and fuse with those of proper specifications.